



SAFETY INFORMATION

- The instrument can be opened and repaired only by qualified personnel. **Unauthorized opening voids the warranty.**
- Do not expose the instrument to rain or moisture.
- Do not locate or store the instrument in excessively dusty or dirty locations.
- Do not locate or store the instrument in locations with excessive vibrations or magnetic fields. Please note that other devices on top or nearby can create problems.
- Do not expose the instrument to direct sunlight.
- Do not operate this equipment close to active antennas to avoid possible interferences.
- Do not apply excessive force to switches or controls in general.
- Be careful not to infiltrate powders and liquids inside the instrument. Nor on the outside.
- If liquids get inside the unit, remove the power immediately to prevent the risk of electric shock and contact a service center as soon as possible.
- Do not clean using abrasive cleaners or liquid cleaners such as benzene or thinner as they may damage the surfaces.
- Do not apply stickers directly on the surfaces to avoid possible damage to paint job.
- Please keep all packaging in case you need to transport the instrument to a service center.
- **Please always check the required voltage and power supply.**
- Never operate the unit with wet hands.
- In case of external power supply, only use the original unit provided with the instrument.
- If an AC adapter is not provided, read and carefully follow specifications for power supply.
- If ventilation holes are present, make sure there's no obstruction to the air flow.
- If the instrument has a serial number, make note of it and be sure it matches serial number on the box.

WARRANTY

- **Crumar Instruments are subject to 12 months manufacturer's warranty.** You always need to contact the seller first even if your instrument is showing defect within this period.
- Warranty extensions are at the discretion of the retailer.
- Damages caused by misuse, improper maintenance or transportation are not covered by this warranty.
- During the warranty period, the customer is entitled to repair or replacement of any parts considered defective at no charge. **The possible replacement of the entire product is at the manufacturer's discretion.**
- If the instrument is designed in a "suitcase-style" version, please note that it doesn't comply with A.T.A. regulations and should not be considered a carrying case.
- If the instrument is designed in a "suitcase-style" version, all external parts (handles, hinges, locks, edge protectors, lids, hoods, etc.) are subject to wear and intended mainly for aesthetic reasons and are not covered by this warranty.
- If the instrument comes with free accessories (cables, sustain pedals, stands, legs, external USB devices, or any kind of accessory either optional or necessary to the operation of the instrument), those are not covered by this warranty.
- If the instrument is returned under warranty within the 12 month coverage, but shows clear signs of carelessness or aesthetic or technical modifications, Crumar reserves the right to reject the warranty claim.

- If the instrument is returned for repair and presents damages from transport due to improper packaging, Crumar reserves the right to reject the warranty claim and terminate the warranty coverage. **Please always use the original box.**
- Removing the serial number label immediately voids the warranty.
- Any modification or alteration to the structure of the instrument, either external or internal, immediately voids the warranty.
- Crumar reserves the right to change the terms of limited warranty without any prior notice and at its sole discretion.
- If the instrument comes with a keyboard, please note that the action/stiffness/response/noise of it changes over time due to temperature/usage/storing conditions. This has to be considered normal and is not covered by this warranty.
- Incompatibility with other devices connected to your instrument using wired or wireless systems is not considered a malfunction and is not covered by this warranty.
- Shipping/transportation costs are always excluded and need to be paid by the customers/retailers.

COPYRIGHT WARNING

- This professional device is intended only for use with works for which you own the copyright, for which you have received permission from the copyright holder to publicly perform, record, broadcast, sell, and duplicate, or in connection with activities which constitute "fair use" under copyright law.
- If you are not the copyright holder, have not received permission from the copyright holder, or have not engaged in fair use of the works, you may be violating copyright law, and may be liable for damages and penalties.
- If you are unsure about your rights to a work, please consult a copyright attorney. **CRUMAR TAKES NO RESPONSIBILITY FOR ANY INFRINGEMENT COMMITTED THROUGH USE OF CRUMAR PRODUCTS.**
- All product names and company names are the trademarks or registered trademarks of their respective owners.

THE FCC REGULATION WARNING (for USA)

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
- These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
- However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected, consult the dealer or an experienced radio/TV technician for help.
- If items such as cables are included with this equipment, you must use those included items.
- Unauthorized changes or modification to this system can void the user's authority to operate this equipment